

# Instructions for fitting PVC Edging using the Cold Weld Technique

**Tools required:** 1 container of Cold weld paste (included in the kit) • 1 Mat • Edging • Weights • Sharp Knife • Straight Edge.

**Preparation:** It is recommended that the work be carried out inside a well ventilated area. A flat clean floor area is essential. Unroll the matting to be edged and the edging itself to allow them to flatten out. Depending on duration of storage and ambient temperature, this process may take 24 hours. Be sure to do this prior to welding.

## Procedure:

